CABINET PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

REFRIGERATOR



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
		LITERATURE PARTS
1	LIT2221517	Use & Care Guide
	LIT2214447	Service & Wiring Sheet
	LIT2219970	Energy Label
	LIT628370	Modular Icemaker Service Sheet
2	2203007	Front Roller (2)
3	3400512	Bolt
4	2203008	Roller (Rear) (2)
5	3400511	Bolt
6	2209558	Clip, Grille
7	489478	Screw
8	2209529	Clip
9	2156056	Shim
10	3400515	Screw
12		Hinge Top
	2203124W	Right, White
	2203124T	Right, Biscuit
	2203124B	Right, Black
	2199935W	Left, White
	2199935T	Left, Biscuit
	2199935B	Left, Black
16	2208137	Hinge & Cam Assy
17	488649	Screw
19	3400103	Screw
20	981126	Pin
21		Filler, Wrapper
	2203067W	White
	2203067T	Biscuit
	2203067B	Black
22		Grille
	2199904W	White
	2199904T	Biscuit
	2199904B	Black
23	489497	Screw
24	2199840	Housing, Water Filter
25	2203220	Water Filter
26	489478	Screw
27		Cap, Water Filter
	2186494W	White
	2186494T	Biscuit
	2186494B	Black
35	489464	Screw
41	940139	Drain Fitting
42	2199954	Extension Tube
43	1108439	Clip, Drain Tube
47	2214385	Cover, Unit
48		Cabinet (Not A Serviceable Part)
52	549193	Clamp, Service Cord
53	489084	Screw

REFRIGERATOR LINER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	1116793	Cover, Thermistor
3	2213442	Thermistor
4	2209204	Clip, Thermistor
5	2220377	Air Baffle
9	2181796	Ladder, Shelf
10	489478	Screw
16	2179404	Rack, Wine & Egg
24	2214367	Air Diffuser Assembly
29	2162085	Socket
31	2196171	Reservoir
33	527949	Light Bulb
34	2203266	Light Lens
35	2205813	Strap
37	489478	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2203053	Shelf Assembly Spillguard (3)
3	2209698	Cover, Crisper
5	2174150	Glass, Cover
6	2179259	Glass, Cover
8	2209698	Cover, Meat Pan
10	2196232	Crisper Pan
11	2179343	Front, Crisper Pan
12	2179342	Slide, Humidity Control
13	2194913	Trim, Handle
14	2209678	Meat Pan
15	2216624	Egg Bin
19	2179234	Trim, Handle
20	2196483	Stud Assembly
21	2196485	Stud Assembly
22	2203027	Cover, Beverage
23	2203028	Beverage Pan
24	2203031	Handle, Beverage
25	2188212	Roller
26	2174478	Eyelet, Roller
27	489261	Screw
28	8281158	Screw
29	3400894	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
2	2209204	Clip, Thermistor
3	2199860	Door, Ice Compartment
5	2174478	Eyelet, Roller
6	842534	Clip, Air Duct (2)
7	2196206	Support, Stud (4)
8	2213442	Thermistor
9	2199867	Trim, Basket
10	2199863	Basket (2)
11	2199892	Basket, Shallow
12	2188212	Roller
13	1116793	Cover, Thermistor
14	2203111	Wiring Cover
15	489464	Screw
16	489211	Screw
17		Slide, Basket
	2208198	Right Side (2)
	2208197	Left Side (2)
18	489355	Screw
19	1115373	Switch, Rocker Arm
20	2196483	Stud (12)
21	489478	Screw
22	1113169	Stop, Roller
23	2203022	Shelf, Top Compartment
24	2199965	Light Lens
25	527949	Light Bulb
26	2162085	Light Socket
28		Slide, Container
	2002721	Left Side
	2002720	Right Side
29	2003478	Screw
30	8281158	Screw (12)
31	2199861	Shelf
32	3400893	Screw (4)

MOTOR AND ICE CONTAINER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2214579	Bracket, Motor
2	2188385	Motor, Dispenser
3	2152713	Soleniod Assembly
4	2149100	Guide, Solenoid
7	2206503	Wiring Assembly, Ice Dispenser
8	489399	Screw
9	2205716	Coupling, Motor
10	489355	Screw
11	2162085	Socket, Light
14	2199895	Ice Container
15	983668	Coupling, Conveyor
18	1119005	Spacer, Step (3)
19	1119007	Spacer, Flat (2)
20	1119006	Blade, Rotary
21	1119012	Blade, Rotary
22	1119013	Blade, Rotary
23	489235	Washer, Plain
24	1119009	Blade, Fixed (2)
25	2157405	Block, Blade
26	489229	Roll Pin
27	2160602	Conveyor
28	2196194	Drum
29	3400912	Washer
30	2171682	Floating Baffle
31	1119018	Nut, Bearing
32	2002728	Control Arm
33	1119020	Spring, Return
34	1119021	Retainer Clip, Rod
35	488886	Screw
37	2180348	Housing, Crusher
38	1119017	Deflector, Ice
39	489234	Washer, Plain
40	489236	Retainer Ring
44	2199913	Front Cover, Ice Container
45	527949	Light Bulb
46	2171706	Light Lens, Dispenser

REFRIGERATOR DOOR PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #8)
	2210773W	White
	2210773T	Biscuit
	2210773B	Black
3	2177105	Door, Compartment
4	2182190	Trim, Door Shelf
5	3196537	Screw
6	2199986	Bin, Door
7		Trim, Door−Bottom
	2207314W	White
	2207314T	Biscuit
	2207314B	Black
8		Door Gasket, Magnetic
	2209561	Mist Beige
	2209563	Black
9		Handle
	2207308W	White
	2207308T	Biscuit
	2207308B	Black
10	3400012	Screw
11		Trim, Hinge−Side
	2207310W	White
	2207310T	Biscuit
	2207310B	Black
12	2195497	Divider, Bin
13		Trim, Door−Top
	2207312W	White
	2207312T	Biscuit
	2207312B	Black
14	2182179	Door Closer, Upper Cam
15	489420	Screw
16		Bracket, Door Stop
	2210774	Chrome
	2214451	Black
17	1113948	Retainer, Shelf Ladder (2)
18	1113949	Ladder, Shelf (2)
19	2203087	Trim, Door Shelf
20	3196180	Screw
21	2165792	Butter Dish
22	2199983	Bin, Door (3)
23	2195916	Endcap (2)

FREEZER DOOR PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item #8 And Dispenser Front Parts)
	2214475W	White
	2214475T	Biscuit
	2214475B	Black
2		Handle
	2207309W	White
	2207309T	Biscuit
	2207309B	Black
3	3400012	Screw
4	3196537	Screw
5		Trim, Hinge−Side
	2207311W	White
	2207311T	Biscuit
	2207311B	Black
6	2199990	Trim, Door Shelf
8		Door Gasket, Magnetic
	2209560	Mist Beige
	2209562	Black
9	2199991	Trim, Door Shelf
10	488500	Screw
11	2187667	Wiring Harness, Freezer Door
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2210774	Chrome
	2214451	Black
15	2156006	Plug, Trim
17		Trim, Door−Bottom
	2207315W	White
	2207315T	Biscuit
	2207315B	Black
18		Trim, Door−Top
	2207313W	White
	2207313T	Biscuit
	2207313B	Black
19	2208147	Ladder Shelf, Assembly (2)
21	3196180	Screw
22	2195916	Endcap
23	2199992	Bin, Door (2)
24	2195917	Endcap

DISPENSER FRONT PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	489101	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2180323	White
	2186860	Biscuit
	2180325	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2180259	White (White Shadow Pad)
	2186850	Biscuit (Almond Shadow Pad)
	2180261	Black (Storm Grey Pad)
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (2)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2180268	White (White Shadow Pad)
	2186852	Biscuit (Almond Shadow Pad)
	2180270	Black (Storm Grey Pad)
18		Switch Assembly (Not Available, Order #23)
19		Overlay, Front Cover (Not Available, Order #23)
20	2196199	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2199902W	White
	2199902T	Biscuit
	2199902B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	2203170	Wire Harness, Control Mounting Bracket

UNIT PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2205983	Condenser Assembly
4	489464	Screw
5	2155658	Clip, Wire
6	2214366	Tube, Condenser to Heat Loop
7	2185788	Clamp, Tube
8	2161302	Sleeve
9	2158826	Dampener
10	2210750	Bracket, Insert
11	8281197	Screw
12	2215676	Cover, Terminal
13	2214361	Wire Assembly
14	2214365	Tube Suction
15	2203876	Gasket
16	2203020	Extension, Air Baffle
17	2209324	Inverter Box
18	2163787	Clip, Compressor Mounting (4)
19	2208183	Block, Evaporator
20	2199929	Housing, Control Board
21	489478	Screw
22	2209611	Evaporator
23	2161324	Clamp
24	2206036	Fan, Motor
25	1105523	Tray, Evaporator
27	2199167	Drier
28	2208937	Compressor (Includes Items 12, & 27) (Also Order 876765 Tube Kit)
29	2203075	Spacer
30	2210728	Unit Mounting Plate
31	2212052	Unit, Harness
32	2208157	Fan, Motor Bracket
33	2210737	Heater, Defrost
34	2161330	Clip
35	8281196	Screw
36	2221536	Board, Control
37	680975	Washer
39	2163786	Grommet (4)
40	3400515	Screw
42	2199806	Tube, Heat Loop
43	489491	Screw
45	3400514	Screw
46	2214509	Insulation, Mounting Plate
47	2203160	Side Support
52	2205813	Strap
54	227991	Wire Connector
63	2196152	Union

Following Parts Not Illustrated and Optional Parts Not Included

Part No.	
978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

6.25 oz.
(R−134A)

AIR FLOW PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2182120	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2210746	Air Scoop
4	2208184	Block, Fan Scroll
5	2199931	Air Duct Freezer
7	2208939	Fan Motor
8	2169142	Fan Blade
10	2208959	Fan Grommet
11	2182146	Duct, Icemaker
12	2214359	Harness, Fan Evaporator, And Heater, Bi−Metal
13	2155789	Gasket Cover
14	2205813	Wire Tie
16	2210780	Gasket
17	2203122	Cover, Evaporator
18	489464	Screw
19		Evaporator, Cover Rail
	2199922	Right
	2199923	Left
21	489478	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2203081	Overlay
2	2208141	Retainer, Circuit Board
3	2214765	Circuit Board, Interface
4	2199717	Control Box
5	2203108	Light Lens
6	940014	Hole Plug
17	2162085	Light Socket
19	850166	Light Bulb
20	2220781	Control Box Harness

ICEMAKER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
3	2203127	Tube, Filter Outlet
4	2214613	Tube, Filter Inlet
5	628379	Clip, Fuse
7	2181940	Tube, Water
8	2181939	Insert, Tube
9	489478	Screw
10	2199838	Valve, Solenoid
11	627018	Nut, Compression
12	2208136	Clip, Water Tube
13	2203024	Tube, Water Inlet
14	488878	Tube Clamp
18	2174155	Cover
19	488649	Screw
20	628228	Mold & Heater Assembly (Also Order 542638
22	628356	Cup, Water Fill
23	2194711	Ejector
24	2182124	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	628397	Thermostat (Also Order 542369 Cement Alumilastic)
28	489322	Screw
30	489276	Screw
31	2171593	Shut Off Arm
32	628256	Harness, Wiring
33	628320	Bracket
35	628399	Module Assembly (Includes Items 37 and 38)
36	488208	Screw
37	628398	Motor
38	489136	Screw
40	1129179	Nut, Compression
100	4317943	Complete Icemaker Assembly

PARTS NOT ILLUSTRATED

For Models: GC5THGXKQ00, GC5THGXKT00, GC5THGXKB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

*350942	Primer, White (13 Oz. Spray Can)
*350939	Enamel, Black (13 Oz. Spray Can)
*350930	Enamel, White (13 Oz. Spray Can)
*4392901	Enamel, Biscuit (13 Oz. Spray Can)
72017	Brush Touch−Up Kit (White)
4392899	Brush Touch−Up Kit (Biscuit)
72032	Brush Touch−up Kit (Black)

*__Caution:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

212643	Sealer, Gum (4 Feet)
479502	Tape, Vinyl (3/4 x 108")
876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
505587	Sealer, Mastic (1 Qt.)
503695	Cork, Sealer (1/4 Pound)
511873	Touch−Up, White Porcelain (2 Oz.)
542638	Grease, Silicone (1/2 Oz.)
542639	Cement, Alumilastic (1−1/4 Oz.)
606755	Bag, Insulation (36−5/8" x 46")
799833	Kit, Evaporator Repair (Aluminum Epoxy)
833938	Kit, Terminal Connector
2199894	Ice Contianer Assembly
2160606	Ice Crusher Mechanism Assembly

Refinishing Material

799340	Enamel, Black (1 Qt. Uncut)
799344	Enamel, White (1 Qt. Uncut)
4392900	Enamel, Biscuit (1 Qt. Uncut)

TORX SCREW WRENCH

1117510	Torx Key